

E-1 气缸头组合 (CYLINDER HEAD ASSY)



E-1 气缸头组合 (CYLINDER HEAD ASSY)					
序号 Ref No.	件号 Part No.	中文名称 Chinese	英文名称 Description	数量 Q'ty	
1	1010010-167FMM	气缸头组件	Cylinder head assy	1	
2	1010017-167FMM	气缸头盖	Cylinder head cover	1	
3	GB5789-88	螺栓M6×28	Bolt M6×28	3	
4	GB5787-88	螺栓M6×12	Bolt M6×12	1	
5	GB97-83	铜垫φ6	Washer 6	1	
6	1010040-167FMM	气缸头盖密封O形圈	Gasket,cylinder cover	1	
7	GB/T 6170-2000	螺母M6	Nut M6	4	
8	1100003-167FMM	进气管组件	Pipe comp,intake	1	
9	GB5783-88	螺栓M6×20	Bolt M6×20	2	
10	1030404-167FMM	O形圈33.5×3	O-Ring 33.5×3	1	
11	1010005-167FMM	螺栓M8×79	Bolt M8×79	1	
12	GB97-83	铜垫φ8	Washer 8	1	
13	GB83-83	双头螺栓M6×35	Stud M6×35	2	
14	1060511-167FMM	气门油封	Oil-Ssal,Valve	2	
15	1150900-167FMM	火花塞	Spark plug(D8EA)	1	
16					
17					
18					
19					
20					
21					

E-2 气缸体组合 (CYLINDER BODY)



E-2 气缸体组合 (CYLINDER BODY)					
序号 Ref No.	件号 Part No.	中文名称 Chinese	英文名称 Description	数量 Q'ty	
1	1010040-167FMM	气缸头密封垫	Gasket,cylinder hsad	1	
2	1000053-167FMM	定位销φ10×20	Position pin 10×20	3	
3	GB3452.1-92	O形圈10×1.6	O-Ring 10×1.6	1	
4	GB5789-88	螺栓M6×22	Bolt M6×22	2	
5	1000024-167FMM	气缸体密封垫	Cylinder gasket	1	
6	1020000-167FMM	气缸体	Cylinder body comp	1	
7					
8					
9					
10					
11					
12					
13					
14					
15					
16					
17					
18					
19					
20					
21					

E-3 右曲轴箱盖组合 (R.Crankcase cover assy)




E-3 右曲轴箱盖组合 (R.Crankcase cover assy)					
序号 Ref No.	件号 Part No.	中文名称 Chinese	英文名称 Description	数量 Q'ty	
1	1110410-167FMM	离合器操纵杆组件	Clutch lever assy	1	
2	GB3452.1-92	O形圈6.8x1.9	O-Ring 6.8x1.9	1	
3	1110004-167FMM	操纵杆回位弹簧	Spring	1	
4	1030108-167FMM	离合器分离凸轮	Clutch seperating cam	1	
5	GB91-86	销2x16	Pin 2x16	1	
6	1030121-167FMM	右曲轴箱盖	R.crankcase cover	1	
7	1030112-167FMM	O形圈18x3	O-Ring 18x3	1	
8	1030110-167FMM	机油尺	Oil-ruler	1	
9	1030105-167FMM	定位销φ8x14	Position pin φ8x14	2	
10	1030205-167FMM	右曲轴箱盖纸垫	Gasket,R.crankcase cover	1	
11	1030120-167FMM	机油油面观察窗	Oil-measuring hole	1	
12	1030111-167FMM	转速表齿轮(输出轴)	Gear for tachometor	1	
13	1030112-167FMM	转速表齿轮止推垫圈	Washer,tachometor gear	1	
14	1030120-167FMM	输出轴油封6.5x14.5x7	Oil seal 6.5x14.5x7	1	
15	1030107-167FMM	起动轴油封16x28x7	16x28x7	1	
16	GB5787-88	螺栓M6x50	Bolt M6x50	1	
17	GB5787-88	螺栓M6x40	Bolt M6x40	10	
18	GB520-88	螺钉M5x25	Screw Mx25	1	
19					
20					
21					

E-4 曲轴箱组合 CRANKCASE ASSEMBLY



E-4 曲轴箱组合 CRANKCASE ASSEMBLY					
序号 Ref No	件号 Part No.	中文名称 Chinese	英文名称 Description	数量 Q'ty	
1	GB3452.1-92	O形圈9.4x2.4	O-ring 9.4x2.4	2	
2	GB5783-88	螺栓M6x55	Bolt M6x55	1	
3	1000066-167FMM	离合器拉索支架	Clutch cable stand	1	
4	1020006-167FMM	气缸双头螺栓M8x122	Stud	2	
5	GB97-83	平垫圈φ12	Plain washer φ12	4	
6	1010007-167FMM	气缸盖螺母	Nut	4	
7	1030344-167FMM	废气管	Breath pipe	1	
8	GB895.2-86	废气管卡箍	Clamp	1	
9	1020005-167FMM	气缸双头螺栓M8x130	Stud M8x130	2	
10	1030405-167FMM	定位销φ10x14	Position pin φ10x14	4	
11	1030002-167FMM	曲轴箱纸垫	Gasket,crankcase	1	
12	1030108-167FMM	左曲轴箱体组件	L.crankcase assy	1	
13	1000066-167FMM	凸轮轴压板	Pressing board,cam	1	
14	GB5787-88	螺栓M6x12	Bolt M6x12	2	
15	GB/T 276-1994	滚针轴承HK1010	Sring protector	1	
16	GB5787-88	螺栓M6x50	Bolt M6x50	9	
17	GB5787-88	螺栓M6x95	Bolt M6x95	1	
18	1030302-167FMM	放油螺盖	Screw cover	1	
19	GB3452.1-92	O形圈35x3	O-ring 35x3	1	
20	1080203-167FMM	机油过滤网弹簧	Spring,oil filter element	1	
21	1080201-167FMM	机油过滤网组件	Oil filter element component	1	
22	1000055-167FMM	变速轴油封14x28x7	Gear shift,oil seal	1	

E-4 曲轴箱组合 CRANKCASE ASSEMBLY



E-4 曲轴箱组合 CRANKCASE ASSEMBLY					
序号 Ref No.	件号 Part No.	中文名称 Chinese	英文名称 Description	数量 Q'ty	
23	1060430-167FMM	压销体组件	Pressing pin component	1	
24	GB3452.1-92	O形圈13x2.5	O-ring 13x2.5	1	
25	1000056-167FMM	曲轴油封34x50x7	Oil seal 34x50x7	1	
26	1000065-167FMM	起动齿轮定位板	Start.gear fixture	1	
27	GB/T 276-1994	滚动轴承6202	Rolling bearing 6202	1	
28	1030211-167FMM	右曲轴箱体组件	R.crankcase assy	1	
29	GB/T 276-1994	滚动轴承6204	Rolling bearing 6204	1	
30	GB/T 276-1994	滚动轴承6006	Rolling bearing 6006	1	
31	GB/T 276-1994	滚针轴承NK152312	Needle bearing NK152312	1	
32	1000049-167FMM	副轴油封20x34x7	Sub oil-seal 20x34x7	1	
33	1151500-167FMM	档显组件	Gear indicator	1	
34	GB5783-88	螺栓M6x25	Bolt M6x25	1	
35	1000050-167FMM	变速鼓油封14x22x5	Oil seal 14x22x5	1	
36	1030301-167FMM	放油螺塞垫圈φ12	Washer φ12	1	
37	1030203-167FMM	放油螺栓M12x1.5	Bolt M12x15	1	
38	1000064-167FMM	压线板	Pressing board	1	
39	GB5787-88	螺栓M6x12	Bolt M6x12	1	
40					
41					
42					
43					

E-5 左曲轴箱盖组合 (L.Crankcase cover assy)



E-5 左曲轴箱盖组合 (L.Crankcase cover assy)					
序号 Ref No.	件号 Part No.	中文名称 Chinese	英文名称 Description	数量 Q'ty	
1	GB/T 276-1994	滚针轴承HK1010	Needle bearing HK1010	1	2.07
2	1030108-167FMM	左曲轴箱盖	L.crankcase cover	1	40.60
3	GB5787-88	螺栓M6x20	Bolt M6x20	3	0.12
4	1030356-167FMM	左曲轴箱盖纸垫	Gasket,L.crankcase cover	1	0.47
5	GB3452.1-92	O形圈13.8x2.5	O-ring 13.8x2.5	1	0.08
6	1000058-167FMM	小视孔盖(M14)	Screw cover(M14)	1	1.03
7	GB5787-88	螺栓M6x25	Bolt M6x25	1	0.13
8	GB5787-88	螺栓M6x40	Bolt M6x40	5	0.15
9	GB5787-88	螺栓M6x50	Bolt M6x50	2	0.18
10	1000057-167FMM	大视孔盖(M30)	Screw cover(M30)	1	3.00
11	GB3452.1-92	O形圈27.4x2.4	O-ring 27.4x2.4	1	0.11
12	1030403-167FMM	电机盖	Cover	1	4.65
13	1030109-167FMM	左曲轴箱后盖	Backcover,L.crankcase	1	18.52
14	GB5787-88	螺栓M6x28	Bolt M6x28	2	0.13
15	GB3452.1-92	O形圈63x3	O-ring 63x3	1	0.41
16	GB818-88	螺钉M5x16	Screw M5x16	2	0.08
17	GB5787-88	螺钉M6x28	Screw M6x28	3	0.13
18					
19					
20					
21					

E-6 曲轴活塞连杆组 CRANKSHAFT PISTON CONNECTING ROD COMP



E-6 曲轴活塞连杆组 CRANKSHAFT PISTON CONNECTING ROD COMP					
序号 Ref No.	件号 Part No.	中文名称 Chinese	英文名称 Description	数量 Q'ty	
1	1040000-167FMM	曲轴连杆组件		1	
2	GB5789-88	磁缸锁紧螺栓		1	
3	1050003-167FMM	活塞销档圈		2	
4	1050000-167FMM	活塞		1	
5	1050002-167FMM	活塞销		1	
6	1050100-167FMM	组合环组		1	
7	1080303-167FMM	锁紧螺母		1	
8	1080302-167FMM	碟形垫圈		1	
9					
10					
11					
12					
13					
14					
15					
16					
17					
18					
19					
20					
21					

E-7 配气机构组合 AIR NLET EXHAUST SYSTEM



E-7 配气机构组合 AIR NLET EXHAUST SYSTEM					
序号 Ref No.	件号 Part No.	中文名称 Chinese	英文名称 Description	数量 Q'ty	
1	1060505-167FMM	进气门	Inlet valve	1	
2	1060506-167FMM	排气门	Outlet valve	1	
3	1060508-167FMM	气门弹簧外座圈	Outer, spring seat valve	2	
4	1060502-167FMM	气门弹簧内座圈	Inner, spring seat valve	2	
5	1060504.3-167FMM	气门内、外弹簧	Inner, outer spring	2	
6	1060509-167FMM	气门弹簧座	Spring seat for valve	2	
7	1060501-167FMM	气门锁夹	Lock plates	4	
8	1060210-167FMM	上摇臂座组件	Upper, rocker arm comp	1	
9	GB97-83	铜垫φ8	Washerφ8	3	
10	GB5789-88	螺栓M8×28	Bolt M8×28	3	
11	1060511-167FMM	推杆导架	Guide plate, push lever	1	
12	1060330-167FMM	推杆组件	Push lever comp	2	
13	1000067-167FMM	波形垫圈	Washer	1	
14	1060208-167FMM	下摇臂	Lower rocker	2	
15	1060207-167FMM	下摇臂轴	Shaft, lower rocker	1	
16	GB3452.1-92	O形圈17×2.5	O-ring17×2.5	1	
17	1000067-167FMM	凸轮轴压簧	Cam shaft, pressing spring	1	
18	GB3452.1-92	O形圈20×2.5	O-ring20×2.5	1	
19	1060116-167FMM	凸轮轴芯	Shaft, cam	1	
20	1060117-167FMM	止推垫圈φ14	Thrust washer	1	
21	1060110-167FMM	凸轮轴组件	Cam shaft comp	1	

E-8 机油泵及机油滤清器分总成 OIL PUMP.OIL FILTER COMP



E-8 机油泵及机油滤清器分总成 OIL PUMP.OIL FILTER COMP					
序号 Ref No.	件号 Part No.	中文名称 Chinese	英文名称 Description	数量 Q'ty	
1	1070200-167FMM	机油泵组件	Oil pump comp	1	
2	1080301-167FMM	机油滤清器转子组件	Rotor assy,oil filter	1	
3	1080309-167FMM	机油滤清器盖	Cover,oil filter	1	
4	1080305-167FMM	机油滤清器盖密封垫	Gasket,oil filter cover	1	
5	GB818-88	螺钉M5×12	Screw M5×12	3	
6	1110009-167FMM	初级主动齿轮	Primary drive gear	1	
7	GB818-88	螺栓M6×30	Bolt M6×30	2	
8					
9					
10					
11					
12					
13					
14					
15					
16					
17					
18					
19					
20					
21					

E-9 离合器总成 CLUTCH COMP



E-9 离合器总成 CLUTCH COMP					
序号 Ref No.	件号 Part No.	中文名称 Chinese	英文名称 Description	数量 Q'ty	
1	1110001-167FMM	离合器分离杆	Clutch separating rod	1	
2	1130002-167FMM	离合器分离轴套	Asle sleeve, separating	1	
3	GB/T 276-1994	滚动轴承6001	Rolling bearing 6001	1	
4	GB893.1-86	挡圈φ20	Cliripφ20	1	
5	1110013-167FMM	花键垫圈	Washer	1	
6	1110030-167FMM	离合器外壳组合	Clutch housing cover	1	
7	1110034-167FMM	离合器中心套组合	Clutch center piece say	1	
8					
9					
10					
11					
12					
13					
14					
15					
16					
17					
18					
19					
20					
21					

E-10 变速器分总成(I) TRANSMISSION COMP



E-10 变速器分总成(I) TRANSMISSION COMP					
序号 Ref No.	件号 Part No.	中文名称 Chinese	英文名称 Description	数量 Q'ty	
1	1130030-167FMM	主轴组合	Main shaft assy	1	
2	1130010-167FMM	副轴组合	Deive assy	1	
3	1130023-167FMM	主动链轮	Driving gear	1	
4	1130024-167FMM	主动链轮固定板	fixture plate,driving gear	1	
5	GB5783-88	螺栓M6×10	Bolt M6×10	2	
6	1140100-167FMM	起动踏板组合	Starting pedal assy	1	
7	1140100-167FMM	起动轴组合	Starting driving shaft assy	1	
8					
9					
10					
11					
12					
13					
14					
15					
16					
17					
18					
19					
20					
21					

E-11 变速器分总成(II) TRANSMISSION COMP



E-11 变速器分总成(II) TRANSMISSION COMP					
序号 Ref No.	件号 Part No.	中文名称 Chinese	英文名称 Description	数量 Q'ty	
1	1130500-167FMM	变速轴组件	Gear shift assy	1	
2	1130302-167FMM	拨叉(中)	Fork,middle	1	
3	1130303-167FMM	拨叉(左)	Fork,left	1	
4	1130301-167FMM	拨叉(右)	Fork,right	1	
5	1030104-167FMM	拨叉轴	Fork,shaft	1	
6	GB5783-88	螺栓M6x25	Bolt M6x25	1	
7	1130200-167FMM	变速鼓组件	Shift drum assy	1	
8	1130213-167FMM	五星拨板	Shift cam	1	
9	1130405-167FMM	定位板回位弹簧	Spring	1	
10	1130401-167FMM	定位板组件	Stopper lever assy	1	
11	GB5783-88	螺栓M6x20	Bolt M6x20	1	
12	1130300-167FMM	变档踏板组件	gear shift pedal assy	1	
13					
14					
15					
16					
17					
18					
19					
20					
21					

E-12 磁电机分总成 MAGNETO COMP



E-12 磁电机分总成 MAGNETO COMP					
序号 Ref No.	件号 Part No.	中文名称 Chinese	英文名称 Description	数量 Q'ty	
1	1151320-167FMM	转子组合	Fly wheel comp	1	
2	1151330-167FMM	定子组合	Stator assy	1	
3					
4					
5					
6					
7					
8					
9					
10					
11					
12					
13					
14					
15					
16					
17					
18					
19					
20					
21					

E-13 电启动总成 ELECTRIC STARTER ASSY



E-13 电启动总成 ELECTRIC STARTER ASSY					
序号 Ref No.	件号 Part No.	中文名称 Chinese	英文名称 Description	数量 Q'ty	
1	1151400-167FMM	起动机组合	Starting motor assy	1	
2	1120020-167FMM	孔双联齿轴	Axle	1	
3	1120031-167FMM	垫圈φ10	Washerφ10	4	
4	1120030-167FMM	孔双联齿组合	Axle assy	1	
5	1120032-167FMM	轴双联齿轮	Gear,axle	1	
6	1120010-167FMM	减速盘齿组合	Reduction gear assy	1	
7					
8					
9					
10					
11					
12					
13					
14					
15					
16					
17					
18					